












Výrobní možnosti

Čelní válcové soukolí		$m_n = 1 \div 25 \text{ mm}$ $b_{\max} = 600 \text{ mm}$ $d_{0\min} = 30 \text{ mm}$ $L_{\max} = 1800 \text{ mm}$	
		$m_n = 1 \div 25 \text{ mm}$ $b_{\max} = 600 \text{ mm}$ $d_{0\max} = 2000 \text{ mm}$	
Ozubené věnce		$D_i = 260 \div 800 \text{ mm}$ Modul normal $m_n = 3 \div 12 \text{ mm}$ $D_{e,\max} = 1100 \text{ mm}$ 6 DIN3962	
		$D_e = 35 \div 250 \text{ mm}$ Modul normal $m_n = 3 \div 12 \text{ mm}$ 6 DIN3962	
		$D_e = 30 \div 200 \text{ mm}$ Modul normal $m_n = 3 \div 12 \text{ mm}$ 6 DIN3962	
Kruželové soukolí		$m_n = 2,1 \div 8 \text{ mm}$ $b_{\max} = 65 \text{ mm}$ $d_{0\max} = 90 \text{ mm}$ $L_{\max} = 850 \text{ mm}$ $i_{\max} = 6,3$	$m_n = 2,1 \div 12 \text{ mm}$ $b_{\max} = 120 \text{ mm}$ $d_{0\max} = 130 \text{ mm}$ $L_{\max} = 850 \text{ mm}$ $i_{\max} = 6,3$
		$m_n = 2,1 \div 8 \text{ mm}$ $b_{\max} = 65 \text{ mm}$ $d_{0\max} = 400 \text{ mm}$	$m_n = 2,1 \div 12 \text{ mm}$ $b_{\max} = 120 \text{ mm}$ $d_0 = 90 \div 800 \text{ mm}$
		8 DIN3965	6-7 DIN3965
		8 DIN3965	6-7 DIN3965

Šnekové převody válnové jednochodé		$m_n = 2 \div 18 \text{ mm}$ $b = 30 \div 300 \text{ mm}$ $d_0 = 50 \div 180 \text{ mm}$ $L_{max} = 1500 \text{ mm}$... 6 DIN3974	
		$m_n = 2 \div 18 \text{ mm}$ $d_0 = 50 \div 900 \text{ mm}$	
Zubové spojky (ozubení vypouklé)			
	$D_e \text{ (mm)}$	70 ÷ 500	70 ÷ 500
	Modul normal (mm)	3 ÷ 8	3 ÷ 10
	DIN3962	8	6
			
	$D_i \text{ (mm)}$	250 ÷ 800	250 ÷ 800
	Modul normal (mm)	3 ÷ 12	3 ÷ 10
DIN3962	8	6	
$D_{e, max} = 1000 \text{ mm}$			